

Stagg EKG/EKG+

Features Guide



Turn On

Push the main button to turn on your kettle.



HOLD and F/C

Use the back toggles to choose temperature and HOLD settings.



SET Temperature

Twist the main button to SET desired temperature. Screen will show "SET" when temperature is being set.



Heating

When the F/C is blinking, the kettle is heating. The top number on your screen is your SET temp. and the bottom is your current temp.



SET Temp. Reached

Once your SET temp. is reached, your kettle will steadily maintain that temp. thanks to the smart PID controller.



HOLD Mode

Stagg EKG's HOLD mode maintains your SET temperature for 60 minutes when switched on. If HOLD mode is off, your kettle will reach SET temperature, stay there for 5 minutes, then stop heating and go into standby for 15 minutes before turning off.

When you have turned HOLD mode on, the screen will flash "HOLD ON". When your kettle is holding your SET temperature, HOLD will appear at the top of the LCD screen.



Start/Stop Brew Stopwatch

To start or stop the built-in Brew Stopwatch, hold down the main button for 2 seconds. Push main button again to stop the stopwatch and return to main screen.



Turn Off

Push the main button to turn off kettle.